# THANK YOU FOR PURCHASING A HOTPOINT PRODUCT.

To receive more comprehensive assistance, register the appliance on


www.hotpoint.eu/register

# Before using the appliance carefully read the Health and Safety guide.

Before using the machine, it is imperative that the transport bolts are removed. For more detailed instructions on how to remove them, see the Installation Guide.

#### **CONTROL PANEL**

- 1. ON/OFF button
- 2. DRY ONLY button and indicator light
- 3. KEY LOCK button and indicator light
- 4. CLEANING ACTION button
- 5. CLEANING ACTION indicator lights
- 6. START/PAUSE button and indicator light
- 7. DELAY button and indicator light
- 8. DRYING button
- 9. SPIN button
- 10. TEMPERATURE button
- 11. WASH CYCLE SELECTOR KNOB



#### **WASH CYCLE TABLE**

Maximum load 8 kg Power input in off mode 0.5 W / in left-on mode 8 W									Detergents and Additives		Recommended detergent	
Wash cycle		Temperature		Maximum spin	Max. load	Duration	Drying	Wash	Fabric softener	Powder	Liauid	
			Range	(r.p.m.)	(kg)	(Minutes)	۵	1	2			
1	Daily Wash & Dry	40 °C	<b>*</b> -40°C	800	3,0	÷	•	•	0	-	~	
2	Shirts Wash & Dry	40 °C	<b>*</b> -40°C	1000	2,0	isplā		•	0	-	<b>~</b>	
3	Pre Iron	-	-	-	1,5	The duration of the wash cycles can be checked on the display.	-	_	-	-	_	
4	Steam Refresh	_	_	-	2,0		_	_	-	-	-	
5	Cotton (2)	40 °C	<b>※</b> -60°C	1400	8,0		•	•	0	~	~	
6	Synthetics (3)	40 °C	<b>*</b> -60°C	1000	4,5			•	0	~	~	
7	Anti-Stain Quick	40 °C	<b>*</b> -40°C	1200	4,5	pe c		•	0	-	~	
8	Anti-Stain	40 °C	<b>*</b> -40°C	1400	5,0	can		•	0	-	<	
9	White	60 °C	<b>*</b> -90°C	1400	8,0	cles	•	•	0	~	<	
10	Eco Cotton @/40 (1)	60 °C	<b>*</b> -60°C	1400	8,0	y) di	•	•	0	~	<b>~</b>	
11	Coloureds	40 °C	<b>*</b> -40°C	1400	8,0	f the was	•	•	0	-	<b>~</b>	
12	Ultradelicates	30 °C	<b>*</b> -30°C	0	1,0		•	•	0	-	<b>~</b>	
13	Wool	40 °C	<b></b> #-40°C	800	2,0	o u o	•	•	0	-	~	
14	Fast **	30 °C	<b></b>	800	3,5	ıratic	•	•	0	-	~	
4/1/4	Rinse	-	-	1400	8,0	ne dt	•	-	0	-	_	
4	Spin + Pump out *	-	_	1400	8,0	È	•	_	-	-	-	
● Re	● Required dosage O Optional dosage											

The cycle duration indicated on the display or instruction manual is an estimate based on standard conditions. The actual duration may vary in relation to several factors, such as the temperature and pressure of the incoming water, ambient temperature, amount of detergent, load quantity and type, load balancing and any additional options selected.

#### 1) Test programme in compliance with standard EN 50229 (Wash):

This cycle is designed for normally soiled cotton loads and is the most efficient in terms of both electricity and water consumption; it should be used for garments washable at 60°C or at 40°C. The actual washing temperature may differ from the indicated value.


**Test programme in compliance with standard EN 50229 (Drying):** select the 10 wash programme and set the drying level to "A3", for both loads. The first drying cycle must be carried out with the nominal load.

# For all testing institutes:

- 2) Long cotton cycle: set programme 5 at temperature 40°C.
  3) Long synthetics cycle: set cycle 6 at a temperature of 40°C.
- \* By selecting the  $\stackrel{\mathfrak{D}}{\hookrightarrow}$  cycle and excluding the spin cycle, the washer-dryer will drain only.
- \*\* If a drying cycle is also programmed, the machine will run a "wash+dry" programme lasting 45' and a 1kg laundry load

# **PRODUCT DESCRIPTION**

- 1. Top
- 2. Detergent dispenser drawer
- 3. Control panel
- 4. Handle
- 5. Porthole door
- 6. Drain pump (behind the plinth)
- 7. Plinth (removable)
- 8. Adjustable feet (2)



#### **DETERGENT DISPENSER DRAWER**

# Compartment \*:

Do not insert detergent in this compartment. Compartment 1: Washing detergent (powder or liquid)


If liquid detergent is used, the removable plastic partition A (supplied) should be used for proper dosage.

If powder detergent is used, place the partition into slot B.

# Compartment 2: Additives (fabric softeners, etc.)

The fabric softener must not exceed the "MAX" level.

- ! Use powder detergent for white cotton garments, for pre-washing, and for washing at temperatures over 60°C.
- ! Follow the instructions given on the detergent packaging.



# **WASH CYCLES**

Follow the instructions on the symbols of the garment's wash care label. The value indicated in the symbol is the maximum recommended temperature for washing the garment.



**Daily Wash & Dry** 

use programme 1 to wash and dry mixed garments (cotton and synthetics). This cycle may be used to wash and dry loads of up to 3 kg; we recommend the use of liquid detergent.

The use of the steam in this programme is optimised to reduce the formation of creases on garments, making them easier to iron.

Shirts Wash & Dry

Use programme 2 to wash and dry shirts and T-shirts in different fabrics and colours to ensure maximum care. This cycle may be used to wash and dry loads of up to 2 kg. To achieve optimum results, use liquid detergent and pre-treat cuffs, collars and stains. The use of the steam in this programme is optimised to reduce the formation of creases on garments, making them easier to iron.

#### Pre Iron

Use this programme immediately before ironing; max. 1,5 kg load. The use of the steam in this programme is optimised to reduce the formation of creases on garments, making them easier to iron.

Steam Refresh

For refreshing garments, neutralised unpleasant odours and relaxing the fibres by delivering steam into the drum. The garments will be damp at the end of the cycle.

#### Cotton

Suitable for washing towels, underwear, table cloths, etc. made of resistant linen and cotton that are moderately to heavily soiled.

Synthetics

Suitable for washing moderately soiled garments made of synthetic fibres (e.g. polyester, polyacrylic, viscose, etc.) or mixed synthetic-cotton fibres. **Anti-Stain Quick** 

this programme is ideal for washing the most difficult daily stains in 1 hour. It is ideal for mixed fabrics and coloured garments, caring for your clothes as it washes.

If the drying function is selected, a drying cycle automatically activates at the end of the wash cycle that resembles open-air drying, with the added advantages of preserving garments from yellowing due to sunlight exposure and preventing loss of whiteness caused by the possible presence of dust in the air. Dryness level "A2" recommended.

#### Anti-Stain

the programme is suitable to heavily-soiled garments with resistant colours. It ensures a washing class that is higher than the standard class (A class). When running the programme, do not mix garments of different colours. We recommend the use of powder detergent. Pre-treatment with special additives is recommended if there are obstinate stains.

If the drying function is selected, a drying cycle automatically activates at the end of the wash cycle that resembles open-air drying, with the added advantages of preserving garments from yellowing due to sunlight exposure and preventing loss of whiteness caused by the possible presence of dust in the air. Dryness level "A2" recommended.

# White

For heavily soiled whites and resistant colours.

#### **Eco Cottón**

Suitable for washing moderately soiled cotton garments. At  $40^{\circ}$ C and  $60^{\circ}$ C it is the standard cycle for washing cotton garments, and is the most efficient in terms of combined water and electricity consumption.

# Coloureds

for washing coloured cotton garments. This programme is optimised to keep colours bright even after repeated washing.

#### **Ultradelicates**

For washing very delicate garments. It is advisable to turn the garments inside out before washing them. For best results, use liquid detergent on delicate garments.

We recommend turning the garments inside out before washing and placing small items into the special bag for washing delicates. Use liquid detergent on delicate garments for best results.

When selecting an exclusively time-based drying function, a drying cycle is performed at the end of the wash cycle that is particularly delicate, thanks to light handling and appropriate temperature control of the water jet.

The recommended durations are:

1 kg of synthetic garments --> 150 min

1 kg of synthetic and cotton garments --> 180 min

1 kg of cotton garments --> 180 min

The degree of dryness depends on the load and fabric composition.

To wash silk garments and curtains select the cycle 12 and set the "Delicate" level from option 1.3.

Wool - Woolmark Apparel Care - Green:

the wool wash cycle of this machine has been approved by The Woolmark Company for the washing of wool garments labelled as "hand wash" provided that the products are washed according to the instructions on the garment label and those issued by the manufacturer of this washer-dryer. (M1318)



#### ast

For washing lightly soiled garments in a short time. Not suitable for wool, silk and garments to be washed by hand.

#### Rinse

Designed for rinsing and spinning.

#### Spin + Pump out

Designed for spinning and draining the water.

#### DISPLAY

The display is useful when programming the washer-dryer and provides plenty of information.



Section **A** displays the duration of the various available wash cycles and, once the cycle starts, the time remaining to the latter's end (the display will show the maximum duration of the selected cycle which may decrease after a few minutes, as the actual duration varies in relation to the laundry load and the chosen settings); if the DELAY option was set, the display will show the time remaining to the start of the selected wash cycle. Moreover, pressing the relative button allows for visualising the maximum values for the temperature, spin speed or type of drying relative to the

with the selected programme.
The "washing phases" relative to the selected cycle and the "washing phase" of the running cycle appear in section **B**:

selected programme or the most recently selected ones, if compatible

Main Wash

Rinse المُثْلِّع

Spin/Pump out

-Ò- Drying

Section **C** displays – starting from the left – the icons corresponding to "temperature", "spin" and "drying".

The "temperature" bars \* [ ] | indicate the maximum temperature level that can be selected for the chosen cycle.

The "spin" bars  $\emptyset$   $_{\parallel}$   $_{\parallel}$  indicate the maximum spin speed that can be selected for the chosen cycle.

The - - symbol lights up while the drying settings are being adjusted.

# A Locked door indicator

When lit, the symbol indicates that the door is locked. To prevent any damage, wait until the symbol turns off before opening the door. To open the door while a cycle is in progress, press the START/PAUSE button M: if the symbol is off, the door can be opened.

# FIRST-TIME USE

Once the appliance has been installed, and before it is used for the first time, run a wash cycle with detergent and no laundry, by setting the "Auto-Clean" cycle.

#### **DAILY USE**

Prepare the laundry by following the suggestions appearing under the "TIPS AND SUGGESTIONS" section.

- Open the door. Load the laundry while making sure not to exceed the maximum load quantity indicated in the wash cycle table.
- Pull out the detergent dispenser drawer and pour the detergent into the relevant compartments, as described in the "DETERGENT DISPENSER DRAWER" section.
- Close the door.
- The machine automatically displays the maximum temperature and spin speed values for the selected cycle, or the most recently used settings if they are compatible with the selected cycle. Pressing the ⋃ button gradually reduces the temperature down to the cold wash "OFF" setting. Pressing the ⊚ button gradually reduces the spin speed until it is completely excluded ("OFF" setting). Pressing the buttons further restores the maximum allowed values for the selected cycle.
- Select the desired wash cycle.
- Select the desired options.
- Press the START/PAUSE  $\supset$  button to start the wash cycle; the relative indicator light will light up steady green and the door will lock ( $\cap$  symbol on).

# **PAUSING A CYCLE**

To pause the wash cycle, press the START/PAUSE [ ] button again; the indicator light will flash amber. To start the wash cycle from the point at which it was interrupted, press the START/PAUSE [ ] button again.

# OPENING THE DOOR, IF NECESSARY

Once a cycle starts, the  $\bigcap$  symbol turns on to signal that the door cannot be opened. While a wash cycle is running, the door remains locked. To open the door while a cycle is under way, for example, to add or remove garments, press the START/PAUSE \ button to pause the cycle; the indicator light will flash amber. If the 🖰 symbol is not lit, the door may be opened. Press the START/PAUSE \ DO Dutton again to continue the cycle.

#### CHANGING A RUNNING WASH CYCLE

To change a wash cycle while it is in progress, pause the washer-dryer using the START/PAUSE \( \) \( \) button (the relative indicator light will flash amber), ! To cancel a cycle that has already begun, press and hold the ON/OFF  ${}^{ullet}$ button. The cycle will be stopped and the machine will switch off.

#### AT THE END OF THE WASH CYCLE

This will be indicated by the word "END" on the display; when the  $\bigcap$ symbol switches off, the door may be opened. Open the door, unload the laundry and switch off the machine. If you do not press ON/OFF (1) button, the washer-dryer will switch off automatically after about a half of an hour.

#### **OPTIONS**

- If the selected option is not compatible with the set wash cycle, the indicator light will flash and the option will not be activated

#### 🕒 Delay

To set a delayed start for the selected cycle, press the corresponding button repeatedly until the required delay period has been reached. To remove the delayed start setting, press the button until the text "OFF" appears on the display.

Temperature
Each wash cycle has a pre-defined temperature. To modify the temperature, press the button. The value will appear on the display.

Each wash cycle has a pre-defined spin speed. To modify the spin speed, press the (6) button. The value will appear on the display.

#### Ó- Dryinǵ

The first time the button - is pressed, the machine will automatically select the maximum drying cycle which is compatible with the selected wash cycle. Subsequent presses will decrease the drying level and then the drying time, until the cycle is excluded completely ("OFF"). Drying may be set as follows:

#### A - Based on the desired laundry dryness level:

Iron "A1": suitable for clothes which will need ironing afterwards. the remaining dampness softens creases, making them easier to remove. **Hanger "A2":** ideal for clothes which do not need to be dried fully. Cupboard "A3": suitable for laundry which can be put back in a

cupboard without being ironed.

**B** - Based on a set time period: between **30** and **210** minutes. If your laundry load to be washed and dried is much greater than the maximum stated load, perform the wash cycle, and when the cycle is complete, divide the garments into groups and put some of them back in the drum. At this point, follow the instructions provided for a "Dry Only" cycle. Repeat this procedure for the remainder of the load. A coolingdown period is always added to the end of each drying cycle.

Press button to perform the drying-only cycle.

After selecting the desired cycle (compatible with the type of garments), press button to exclude the washing phase and start the drying phase at the maximum level for the selected cycle. The drying level or time may be set and changed by pressing the drying button -\(\'-\).

# Cleaning action

Option makes it possible to optimise washing based on the level of soil in the fabrics and on desired wash cycle intensity.

For heavily-soiled garments press button until the "Intensive" level is reached. This level ensures a high-performance wash due to a larger quantity of water used in the initial phase of the cycle and due to increased drum rotation. It is useful when removing the most stubborn

For lightly-soiled garments or a more delicate treatment of the fabrics, press will button until the "**Delicate**" level is reached. The cycle will reduce drum rotation to ensure washing results that are perfect for delicate garments.

# **™** KEY LOCK

To activate the control panel lock, press and hold the **—O** button for approximately 2 seconds. When the **—O** symbol is lit, the control panel is locked (except for the ON/OFF (1) button). This will prevent accidental modifications to wash cycles, especially when children are at home. To deactivate the control panel lock, press and hold the **—O** button for approximately 2 seconds.

### **TIPS AND SUGGESTIONS**

#### Divide the laundry according to:

Type of fabric (cotton, mixed fibres, synthetics, wool, garments to be hand-washed). Colour (separate coloured garments from whites, wash new coloured garments separately). Delicates (small garments – such as nylon stockings - and items with hooks - such as bras: insert them in a fabric bag).

#### Empty the pockets:

Objects such as coins or lighters can damage the washer-dryer and the drum. Check all buttons.

# **CARE AND MAINTENANCE**

Before performing cleaning and maintenance, switch the washer-dryer off and disconnect it from the mains power. Do not use flammable liquids to clean the washer-dryer.

#### **Cutting off the water and electricity supplies**

Close the water tap after every wash. This will limit wear on the hydraulic system inside the washer-dryer and help to prevent leaks.

Unplug the washer-dryer when cleaning it and during all maintenance work.

#### Cleaning the washer-dryer

The outer parts and rubber components of the appliance can be cleaned using a soft cloth soaked in lukewarm soapy water. Do not use solvents or abrasives.

The washer-dryer has a "Auto-Cleaning" cycle for its internal parts; it must be run without any load in the drum.

To optimise this cycle, it is possible to use either detergent (10% of the quantity specified for lightly soiled garments) or special additives to clean the washer-dryer. We recommend running a cleaning cycle every 40 wash cycles.

To start the programme press button for 5 seconds.

The cycle will start automatically and will run for about 70 minutes. To stop the cycle, press the START/PAUSE **>∭** button.

#### Cleaning the detergent dispenser drawer

Remove the dispenser drawer by lifting and pulling it outwards. Wash it under running water; this procedure should be effected regularly.

#### Caring for the door and drum

Always leave the porthole door ajar in order to prevent unpleasant odours from forming.

#### Cleaning the pump

The washer-dryer is fitted with a self-cleaning pump that does not require any maintenance. Small items (such as coins or buttons) may sometimes fall into the protective pre-chamber situated at the base of the pump. ! Make sure that the wash cycle has ended and unplug the appliance. To access the pre-chamber:

- 1. remove the covering panel on the front side of the machine by inserting a screwdriver in the centre and sides of the panel and using it as
- 2. loosen the drainage pump cover by turning it anti-clockwise: it is normal for some water to leak out;
- clean the inside thoroughly;
- 4. screw the cover back on;
- 5. put the panel back in place, making sure the hooks slot in place before pushing the panel onto the appliance.

#### Checking the water inlet hose

Check the water inlet hose at least once a year. If it is cracked or broken, it must be replaced: during wash cycles, the high pressure of the water could suddenly split the hose open.

! Never use hoses that have already been used.

#### **ACCESSORIES**

Contact our Technical Assistance Service to check whether the following accessories are available for this washer-dryer model.

#### Stackina kit

With this accessory you can secure the tumble dryer to the upper part of your washer-dryer to save space and facilitate loading and unloading of the tumble dryer.

# TRANSPORT AND HANDLING

Do not lift the washer-dryer by gripping it from the upper section. Unplug the appliance and close the water tap. Check that the door and detergent dispenser drawer are tightly closed. Detach the filling hose from the water tap then detach the drain hose. Empty all the water remaining in the hoses and secure the latter so that they do not get damaged during transport. Apply the transport bolts back on. Repeat, in reverse order, the transport bolt removal procedure described in the "Installation instructions".

# **TROUBLESHOOTING**

Your washer-dryer could occasionally fail to work. Before contacting the Technical Assistance Service, make sure that the problem cannot be easily solved using the following list.

Anomalies	Possible causes / Solution
The washer-dryer does not	The appliance is not plugged into the socket fully, or not enough to make contact.
start.	There is no power in the house.
	The washer-dryer door is not closed properly.
	The ON/OFF (1) button has not been pressed.
The wash cycle does not start.	The START/PAUSE ▷ M button has not been pressed.
	The water tap has not been opened.
	A delay has been set for the start time.
	The water inlet hose is not connected to the tap.
	The hose is bent.
The washer-dryer does not fill with water ("H2O" appears on	The water tap has not been opened.
the display).	There is no water supply in the house.
	The pressure is too low.
	The START/PAUSE ▷۩ button has not been pressed.
	The drain hose is not fitted between 65 and 100 cm from the floor.
	The free end of the hose is immersed in water.
The washer-dryer	The wall drainage system is not fitted with a breather pipe.
continuously loads and unloads water.	If the problem persists even after these checks, turn off the water tap, switch the appliance off and contact the Technical Assistance Service. If the home is on one of the upper floors of a building, there may be problems relating to back-siphonage, causing the washer-dryer to fill with water and drain continuously. Special anti-siphon valves are available in shops and help to prevent this inconvenience.
	The cycle does not include drainage: with certain cycles it must be started manually.
The washer-dryer does not drain or spin.	The drain hose is bent.
diam or spin.	The drainage duct is clogged.
	The drum was not unlocked correctly during installation.
The washer-dryer vibrates a lot during the spin cycle.	The washer-dryer is not level.
iot during the spin cycle.	The washer-dryer is tucked between furniture cabinets and the wall.
	The water inlet hose is not screwed on properly.
The washer-dryer leaks.	The detergent dispenser drawer is obstructed.
	The drain hose is not properly attached.
The START/PAUSE [>10] indicator light flash rapidly and an error code appears on the display (e.g.: F-01, F).	Switch off the machine and unplug it, wait for approximately 1 minute and then switch it back on again. If the problem persists, contact the Technical Assistance Service.
There is too much foam.	The detergent is not suitable for machine washing (it should display the text "for washer-dryers" or "hand and machine wash", or the like).
	Too much detergent was used.
	The appliance is not plugged into the socket, or not enough to make contact.
	There has been a power failure.
The washer-dryer does not dry.	The appliance door is not shut properly.
<b>/·</b>	A Delay has been set.
	DRYING is in the OFF position.
The machine can be heard taking in water during the drying cycle.	It is normal for the machine to take in short bursts of water during the drying cycle. This helps keep some internal parts cool, and aids speed of drying.

DEMO MODE: to deactivate this function, switch the washer-dryer OFF. Than press and hold "Start/Pause"  $\square$  button, within 5 seconds press also "ON/OFF"  $\square$  button and hold both buttons for 2 seconds.



# You can download the SAFETY AND INSTALLATION INSTRUCTIONS, OPERATING MANUAL, TECHNICAL SHEET and ENERGY DATA by:

- Visiting the website <a href="http://docs.hotpoint.eu">http://docs.hotpoint.eu</a>.
- Using the QR code.
- Alternatively, contact our Technical Assistance Service (the telephone number is indicated in the warranty booklet). When contacting the Technical Assistance Service, provide the codes shown on the adhesive label applied to the inside of the door.