





SRS-XB31


4-734-038-12(1) ©2018 Sony Corporation Printed in China \* 4 7 3 4 0 3 8 1 2 \* (1)






# 1



# 2



# 3



Android / iPhone




<http://www.sony.net/smcpp/>




Sony Music Center




LIGHT






ON






OFF





Wireless Party Chain



Speaker Add



Android



Speaker Add  
Wireless Party Chain  
Party Booster



[http://rd1.sony.net/help/speaker/srs-xb31/h\\_zz/](http://rd1.sony.net/help/speaker/srs-xb31/h_zz/)