|  | INST                   | RUCTION BOOKLET(*)                     |       |
|--|------------------------|--|-------|
|  | Information            | n for domestic electric hobs           |       |
| Comply wit   | h EU directiv          | re 2009/125/EC - Regulation No 66/2014 |       |
| Brand  |                        | Beko                                   |       |
| Model  |                        | CIHYI21B                               |       |
| Type of hob  |                        | Electrical                             | ×     |
|  |                        | Gas                                    |       |
|  |                        | Mix                                    |       |
| Number of cooking Zo   | ne and or ar           | ea                                     |       |
|  | Radiant Cod            | oking Zone                             |       |
| Heating Technology   | Induction Cooking Zone |  | ×     |
|  | Solid Plates           | Cooking Zone                           |       |
| For circular cooking zones or area: diameter of useful surface area per electric heated cooking  |                        | Front Left Zone                        | 18,0  |
|  |                        | Rear Left Zone                         | 18,0  |
|  |                        | Front Right Zone                       | 15,0  |
| zone, rounded to the n   | nearest 5              | Rear Right Zone                        | 21,0  |
| mm (Ø/cm)  |                        | Right Zone                             | 1.7   |
|  |                        | Center Zone                            | 19    |
|  |                        | Left Zone                              | 97    |
|  |                        | Front Zone                             | 12    |
|  |                        | Rear Zone                              | -     |
| For non-circular cooking zones or<br>areas: length and width of useful<br>surface area per electric heated<br>cooking zone or area, rounded to<br>the nearest 5 mm (LxW)CM |                        | Front Left Zone                        |       |
|  |                        | Rear Left Zone                         | 1-    |
|  |                        | Front Right Zone                       | 1-    |
|  |                        | Rear Right Zone                        | -     |
|  |                        | Right Zone                             |       |
|  |                        | Center Zone                            | 12    |
|  |                        | Left Zone                              | 10    |
|  |                        | Front Zone                             | 12    |
|  |                        | Rear Zone                              | 14    |
| Energy consumption per cooking zone or area calculated per kg EC electric cooking Wh/kg  |                        | Front Left Zone                        | 185,5 |
|  |                        | Rear Left Zone                         | 181,0 |
|  |                        | Front Right Zone                       | 176,4 |
|  |                        | Rear Right Zone                        | 188,2 |
|  |                        | Right Zone                             | -     |
|  |                        | Center Zone                            | 12    |
|  |                        | Left Zone                              | -     |
|  |                        | Front Zone                             | -     |
|  |                        | Rear Zone                              | -     |
| Energy consumption for the hob calculated per kg EC electric hob (Wh/kg)   |                        |  | 182,8 |
| *) only for EU countr  | ies                    | 7757186334 185373447 AA                | en_U  |