商品ID
 SKU编码
 商品名称
 69码
 产品型号
 图号
 物料号
 物料名称

 12103
 1C464EUR
 无线吸尘器
 6970019141916
 XCQ08RM
 RM-1946-432
 1400146032
 RM46海外新西兰说明书(英语)

活力红

新西兰

6970019141916

Manufacturer: ROIDMI Information Technology Co., Ltd.
Address: 4F,C8 Building,No.1699 Huishan Road,Life Science and Technology Park,Huishan District,Wuxi,Jiangsu,PRC
Executive Standard: EN60335-1:2012/A13:2017 EN 60335-2-2:2010/A1:2013 EN 62233:2008 EN 55014-1:2017 EN 55014-2:2015 EN 61000-3-2:2014
EN 61000-3-3:2013
Service Email: wxrm@roidmi.com
For product sales informations please check the website: www.roidmi.com/en


For product sales informationg, please check the website: www.roidmi.com/en Version: V1.0, 07.2019 Made in China 1C464EUR

无线吸尘器S1 Special

Product Model RM-C-Y01KR. RM-C-Y01EU. RM-C-Y01UV. RM-C-Y01UV. RM-C-Y01UV. RM-C-Y01UV. RM-C-Y01UV. RM-C-Y01UV. RM-C-Y01UV. KA3601A-3421000BV. KA3601A-3421000BV. KA3601A-3421000DV. KA3601A-3421000DV. KA3601A-3421000CN

3.Do not use tenioren get close to or play with the matteress brush;
3.Do not use the mattress brush(buy separately) to absorb any small cloth, so as not to create a blockage;
4.When using the extension hose to clean the drawer, first remove the items from the drawer to avoid inhalation damage;
5.Clean the accessories after use, so as not to allow the food residue, cotton wool and other particles to rot after long storage.

XCQ08RM





提供单位 ▶ 无锡睿米信息技术有限公司

项目名称 ▶ R46无线吸尘器

版本号 **V0.2**

设计时间 ▶ 2019.07.09

设计于▶ 魏婷婷

设计审核 ▶ 张志强

样

样品数量 ▶ 10套

| 出血线 | |
|-----|--|
| | |
| 切刀 | |
| 压线 | |
| 齿刀 | |
| | |
| 开槽 | |
| 半穿 | |
| 粘合 | |
| THH | |

比例 1:1 单位 mm 未注尺寸请参考图面尺寸或3D尺寸

| 印刷颜色 ▶ PANTONE Cool Gray 11C+CMYK | 成品尺寸 ▶ 143*225mm | 制作工序 ▶ 印刷+过哑油+裁切+装订 | 必须符合欧盟相关规范及睿米质量管理要求,如ROHS 2.0 检测标准 ▶ REACH、PAHs、POPs、CP65、WEEE、美国、欧洲 国内的包装指令等要求 |
|-----------------------------------|------------------|---------------------|---|
| 物料材质 ▶ 105g哑粉纸 | 特种工艺▶过哑油 | 纹理要求▶ | 色相正确、印迹牢固、套印准确、各色套印工艺要求 ▶ 模切走位≤±0.5mm不露杂色,套印误差≤ 0.1mm |
| 历史版本 ▶ V0.1 | | | |
| 修 改点▶添加适配器型号 | | | |
| 修 改人▶ 魏婷婷/20190709 | | | |

Correct Disposal of this product

This marking indicates that this product should not be disposed with other household wastes throughout the EU. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable reuse of material resources. To return your used device, please use the return and collection systems or contact the retailer where the product was purchased. They can take this product for environmental safe recycling.

Long running, high temperature Restart the machine for use after static cooling

The air inlet pipe of electric brush was blocked or the brush can't work

Clean up the garbage that is attached to the electric rolling brush

The filter is covered with dust Clean or replace the filter

Suction Power Reduction Paper or wool fibers clogged in metal mesh holes Regularly check if the metal mesh is clogged

Air duct between dust cup and host is clogged

Charger Indicator LEDs Not On or Not Flashing During Charging

Air duct between dust cup and host is clogged between dust cup and main machine

Regularly check if there is garbage in the air duct between dust cup and main machine

Regularly check if the power adapter is plugged in properly